

PROMAX WATER LANCE

Promax Imaging is proud to announce that the 'Promax Water Lance'
has been added to its already extensive product range.*

The Promax Water Lance allows refiller's to effectively clean the pre-firing chamber of Lexmark 10N16/17's and G50/1970's **WITHOUT** removing the filter.

After soaking the cartridges in Promax's Lexmark Cleaning Solution the previously hardened substance, that has been the thorn in the side of remanufactures, can easily and quickly be removed using the Promax Water Lance.

The 'Lance', once connected to a water supply, is fitted over the pre firing chamber and fired – allowing water to rush through the chamber and exit through the print head, taking the residual waste with it. The spray from the print head forms a nozzle pattern allowing the user to quickly establish that all the blockages have been cleared. Once the cartridge is clean use the priming device (included) to suck the water from the head, replace the sponge (to be cleaned separately) and fill.

- Clean the pre firing chamber **WITHOUT** replacing the filter
- Can be used with an existing water supply
- Identify nozzle blockages before filling

